

Heated Towel Bars

Many of our vacation rental accommodations have a heated towel bar assembly in the main bathroom.

Turning On To use the electric towel bar, turn on the timer located on the wall near the towel bar. Please turn off the towel bar after you are finished.

Note: Some of the towel bars in our properties have a toggle switch located at the bottom of the towel bar. You can use this switch to turn the heated towel bar on and off. This type of towel bar also has a power cord that needs to be plugged into a power outlet.

Troubleshooting: If the towel bar does not heat after a few minutes, please ensure that the toggle switch is on and that the power cord is plugged into the electric outlet.



***IMPORTANT NOTE:** Please turn off the heated towel bar after use. **DO NOT LEAVE ON** for more than 2 hours.*

Maximum Use: 2-Hours